

## iPECS eMG80 LDP90\*\* Quick Reference Guide

### To Make an Outside Call

- Lift Handset and dial **0** for next available line and dial number. (dial **9** for Reception)
- Or just dial **0** and desired number and talk hands free/lift handset.
- Or repeat above but press desired line key.

### To Answer a Call

- If Phone Ringing: Lift handset or press **SPEAKER** button for hands free
- If Phone Not Ringing: Press flashing line button or **PICKUP** button (if pickup group programmed)

### To Transfer a Call

- While on Call press **TRANS/PGM** button.
- Dial the *station* number.
- Announce Call and Hang up. (To retrieve external party press flashing line key).
- Alternatively press pre-programmed flexible button, announce and hang up.

### To Intercom

- Lift Handset or press **SPEAKER** button.
- Dial the *station* number.

### To Place a Call On Hold

- Press the **HOLD/SAVE** button.
- **Once** for system hold
- **Twice** for exclusive hold

### Redial

- Press the **REDIAL** button, (the volume key can be used to scroll through previous numbers)
- Then press OK to dial

### Mute

- Press **MUTE** button to switch off the microphone (Light on)
- Press **MUTE** button to switch on the microphone (Light off)

### Voice Mail (VSF)

- Press VM button (programed flex button usually last key)
- Follow voice prompts 1= new messages
- 2 = saved messages
- 8 = set greeting
- If you don't have a pre programed key to access voice mail please contact our office for details on password and how to setup key.

### Call Forward

Please note the system can be set with pre assigned call forward (normally to voicemail ) by system admin the details below would be used to override that .

- Dial **5 5 4** or lift the handpiece and press **FWD** softkey
- Select number for call forward type
  - 1** = forward immediate
  - 2** = forward on busy
  - 3** = forward on no answer
  - 4** = forward on busy or no answer (most common)
  - #** = cancel call forward
- After selection dial of type of forward a destination can be entered ie: *station* number (eg:100), *Hunt Group* number (eg: 633 for VM), or *Speed Bin* number you wish to divert to (eg: 2001)

### To Page (All Call)

- Dial **# 0 0 (internal and external)** or
- Dial **# 3 (internal only)** or
- Dial **# 5 (external only)**
- Lift handset and wait for tone before speaking.

### Making a Conference Call

- Dial first call
- Press **CONF** softkey or button (first call is placed on hold)
- Dial second call (external or internal) once second call connected
- Press **CONF** key twice to join all calls.

### To Park a Call (if programed)

- Press **PARK** key (601, 602 etc) to park and retrieve.

### Do Not Disturb

- Press **DND** button.
- Repeat to remove

### Program Speed Dial

Press **TRANS/PGM** key

- Press **SPEED** key (right arrow with line to right of 6 key)
- Display will show next available speed bin number
- Dial bin number to add or change. (ie 2000)
- Dial **0** for outside line
- Dial external phone number, Press **HOLD/SAVE**
- Enter name, Press **HOLD/SAVE**
- Press **SPEAKER** button to exit or enter next bin number.

### Use Speed Dial

- Press **SPEED** key (right arrow with line to right of 6 key)
- Dial bin number or
- Press **SPEED** key twice to use dial by name, then volume or digit to select internal, station or system speed bins, then ok or send.

### Station Name Program

- Press **TRANS/PGM** button
- Dial **7 4**
- *Enter in Station name label using number chart on last page*
- Press **HOLD/SAVE** button when done

### Change System Date and Time (only at the system attendant phone)

- Press **TRANS/PGM** button
- Dial **0 4 1**
- Prompts for date entry (MM/DD/YY)
- Dial date eg: 040115 (1<sup>st</sup> April 2015)
- Press **HOLD/SAVE**
- Prompts time entry (HH:MM)
- Dial time eg: 1315 (01:15pm)
- Press **HOLD/SAVE**

### **System Night Switch (only at the system attendant phone)**

*This changes the way the telephone system will behave for incoming calls if setup by your technician*

- Press **DND** button (circle with cross)
- Prompt *Select Ring Mode (1-4)*
- Then dial the number next to the following options
  1. **Day (Normal display)**
  2. **Night**
  3. **Timed Ring Mode (set by technician)**
  4. **Auto Ring Mode (set by technician)**
- Press **HOLD/SAVE** to set

### **Program Flexible Button**

- Press **TRANS/PGM** button
- Press flexible button to program
- Dial feature eg: *Station No. (200)*, or speed and bin number, TEL NUM 0 phone number
- Press **HOLD/SAVE** button
- Press **SPEAKER** button to exit

### **To Erase Flexible Button**

- Press **TRANS/PGM** button
- Press flexible button to program
- Press **HOLD/SAVE** button

### **Number and Letter Code Chart for 9000 Series iPECS Handsets**

10 = 1	20 = 2	30 = 0	etc
21 = A	22 = B	23 = C	
31 = D	32 = E	33 = F	
41 = G	42 = H	43 = I	
51 = J	52 = K	53 = L	
61 = M	62 = N	63 = F	
71 = P	72 = R	73 = S	74 = P
81 = T	82 = U	83 = V	
91 = W	92 = X	93 = Y	9# = Z
*1 = SPACE	SPEED = DELETE		